

## Data Sheet

Product name: Ujeta Care-AK 045  
 Article number: 400 100.DE.001.002

### Product description:

The Ujeta Care is used with contaminated surface water (rivers, freshwater lakes, springs, etc.) and can be operated without electricity and in any location.

All the components required are packaged in the Ujeta Care ready for transport, and the system can be set up in just a few simple steps, without the need for tools.

The Ujeta Care comprises 4 filter systems - a pre-filter, a Cartridge L-AK 045, an activated carbon filter and a membrane filter.

The Ujeta Care is equipped with an Aqua Stop, which enables water to be transported in the water container, allowing the pump unit to remain on-site.

### Technical data:

External measurements (LxWxH): approx. 330 x 160 x 440 mm

Weight (packed): approx. 3.5 kg

Max. fill capacity: 10 litres

Main colours: Blue / black

Material: PP / POM / stainless steel

Filter medium: 1x Cartridge L-AK 045, 1x activated carbon, 1x membrane filter, 1x pre-filter

Operating life: The filters must be replaced after max. 6 months or max. 5,000 litres of cold water.

Earlier replacement may be necessary if the water flow through the device is noticeably reduced and the pumping pressure increases. This is generally an indication of the increased presence of fine particles in the unfiltered water.

Use: Only for cold water up to max. 25°C.

Note: Before first use, pump through min. 2-3 litres of cold water, unused, and discard it. If you have not used the Ujeta Care for an extended period, pump out the water still in the filters, unused, and discard this volume of water.

The screw cover on the Cartridge L-AK 045 can be opened, allowing the filter cartridge inside to be replaced. To ensure that the new filter cartridge is installed correctly, we recommend having it installed by a specialist company.

Please use a new sealing ring every time after opening and closing the Cartridge L-AK 045.

No liability is accepted for filter cartridges that are not correctly installed. Protect the Ujeta Care-AK 045 against frost.

Comments: The purpose for which our products are used is at the purchaser's sole discretion. We recommend carrying out appropriate trials to test their suitability. All details of measurements and capacities are approximate. Subject to change without notice.

Last revised: 12.06.2017



## Data Sheet

Product name: Ujeta Care-MAK 015  
 Article number: 400 100.DE.001.003

### Product description:

The Ujeta Care is used with contaminated surface water (rivers, freshwater lakes, springs, etc.) and can be operated without electricity and in any location.

All the components required are packaged in the Ujeta Care ready for transport, and the system can be set up in just a few simple steps, without the need for tools.

The Ujeta Care comprises 4 filter systems - a pre-filter, a Cartridge L-MAK 015, an activated carbon filter and a membrane filter.

The Ujeta Care is equipped with an Aqua Stop, which enables water to be transported in the water container, allowing the pump unit to remain on-site.

### Technical data:

External measurements (LxWxH): approx. 330 x 160 x 440 mm

Weight (packed): approx. 3.5 kg

Max. fill capacity: 10 litres

Main colours: Blue / black

Material: PP / POM / stainless steel

Filter medium: 1x Cartridge L-MAK 015, 1x activated carbon, 1x membrane filter, 1x pre-filter

Operating life: The filters must be replaced after max. 6 months or max. 5,000 litres of cold water.

Earlier replacement may be necessary if the water flow through the device is noticeably reduced and the pumping pressure increases. This is generally an indication of the increased presence of fine particles in the unfiltered water.

Use: Only for cold water up to max. 25°C.

Note: Before first use, pump through min. 2-3 litres of cold water, unused, and discard it. If you have not used the Ujeta Care for an extended period, pump out the water still in the filters, unused, and discard this volume of water.

The screw cover on the Cartridge L-MAK 015 can be opened, allowing the filter cartridge inside to be replaced. To ensure that the new filter cartridge is installed correctly, we recommend having it installed by a specialist company.

Please use a new sealing ring every time after opening and closing the Cartridge L-MAK 015.

No liability is accepted for filter cartridges that are not correctly installed. Protect the Ujeta Care-MAK 015 against frost.



Comments: The purpose for which our products are used is at the purchaser's sole discretion. We recommend carrying out appropriate trials to test their suitability. All details of measurements and capacities are approximate. Subject to change without notice.

Last revised: 12.06.2017

## Data Sheet

Product name: Ujeta Care-VF 01  
 Article number: 400 100.DE.001.001

### Product description:

The Ujeta Care is used with contaminated surface water (rivers, freshwater lakes, springs, etc.) and can be operated without electricity and in any location.

All the components required are packaged in the Ujeta Care ready for transport, and the system can be set up in just a few simple steps, without the need for tools.

The Ujeta Care comprises 4 filter systems - a pre-filter, a Cartridge L-VF 01, an activated carbon filter and a membrane filter.

The Ujeta Care is equipped with an Aqua Stop, which enables water to be transported in the water container, allowing the pump unit to remain on-site.

### Technical data:

External measurements (LxWxH): approx. 330 x 160 x 440 mm

Weight (packed): approx. 3.2 kg

Max. fill capacity: 10 litres

Main colours: Blue / black

Material: PP / POM / stainless steel

Filter medium: 1x Cartridge L-VF 01, 1x activated carbon, 1x membrane filter, 1x pre-filter

Operating life: The filters must be replaced after max. 6 months or max. 5,000 litres of cold water.

Earlier replacement may be necessary if the water flow through the device is noticeably reduced and the pumping pressure increases. This is generally an indication of the increased presence of fine particles in the unfiltered water.

Use: Only for cold water up to max. 25°C.

Note: Before first use, pump through min. 2-3 litres of cold water, unused, and discard it. If you have not used the Ujeta Care for an extended period, pump out the water still in the filters, unused, and discard this volume of water.

The screw cover on the Cartridge L-VF 01 can be opened, allowing the filter cartridge inside to be replaced. To ensure that the new filter cartridge is installed correctly, we recommend having it installed by a specialist company.

Please use a new sealing ring every time after opening and closing the Cartridge L-VF 01.

No liability is accepted for filter cartridges that are not correctly installed.

Protect the Ujeta Care-VF 01 against frost.



Comments: The purpose for which our products are used is at the purchaser's sole discretion. We recommend carrying out appropriate trials to test their suitability. All details of measurements and capacities are approximate. Subject to change without notice.

Last revised: 12.06.2017